









# Marksman Pivot Kill Wiring (208-08-3329Y2)





Marksman Pivot Kill Output (R2) contact can be placed anywhere in series with the safety circuit, here it is shown at the end before the safety coil.

Pivot Side of Relay Circuits  
Max Amps: 15

Safety Circuit  
Connection "A"  
Connection "B"

Marksman Pivot Kill  
Output (R2)  
781-1C-12D  
12VDC Coil



*If the Pivot Kill Output connector is unplugged from the controller or the controller power is off, the Pivot Kill signal will be in bypass.*