

396-2917Y1 2" Poly Mixing Chamber Installation Instructions



Kit Number: 520-00-145150 **Kit Description:** 2" Mixing chamber with 1" HB Inlets and 1" HB Outlet



Kit Number: 520-00-145155 **Kit Description:** 2" Mixing Chamber with 1" &1-1/2" HB Inlet and 1-1/2" HB Outlet



Kit Number: 520-00-145160 **Kit Description:** 2" Mixing Chamber with 1-1/2" HB & 3/8" QC Inlets and 1-1/2" HB Outlet


396-2917Y1—2" Poly Mixing Chamber Instruction Sheet

Page 1 © 2022 SurePoint Ag Systems, Inc. Revised: 4/14/2022



Parts List and Exploded View Kit: 520-00-145150

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	105-200YG45	2" Manifold Y with 3/4" gauge port	1
2	136-MCV200	2" Poly Flanged Check Valve	2
3	105-FC200	2" Manifold Clamp	5
4	100-200100RB	2" MPT x 1" FPT Reducer Bushing	1
5	105-200100BRB	2" Flange x 1" Hose Barb	2
6	105-150G	1 1/2" EPDM Gasket	5
7	105-200MPT	2" Manifold x 2" MPT	1
8	100-075PLUG	3/4" Pipe Plug	1
9	716-01-100150	Poly 2" Mixing Chamber	1
10	101-100100	1" MPT x 1" HB	1



1" Hose Inlet


General Instructions:

- 1. Assemble Mixing Chamber fittings as shown.
- 2. Connect hose coming from each pump (after the flowmeter) to inlet hose barbs.
- 3. Connect hose from system (Section Valves, LiquiShift, Flow Indicators, etc.) to outlet hose barb.



Parts List and Exploded View Kit: 520-00-145155

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	105-200YG45	2" Manifold Y with 3/4" gauge port	1
2	136-MCV200	2" Poly Flanged Check Valve	2
3	105-FC200	2" Manifold Clamp	5
4	105-200150BRB	2" Manifold X 1-1/2" Barb	1
5	105-200100BRB	2" Flange x 1" Hose Barb	1
6	105-150G	1 1/2" EPDM Gasket	5
7	105-200MPT	2" Manifold x 2" MPT	1
8	100-075PLUG	3/4" Pipe Plug	1
9	716-01-100150	Poly 2" Mixing Chamber	1
10	101-200150	2" MPT x 1-1/2" HB	1




General Instructions:

- 1. Assemble Mixing Chamber fittings as shown.
- 2. Connect hose coming from each pump (after the flowmeter) to inlet hose barbs.
- 3. Connect hose from system (Section Valves, LiquiShift, Flow Indicators, etc.) to outlet hose barb.



Parts List and Exploded View Kit: 520-00-145160

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	105-200YG45	2" Manifold Y with 3/4" gauge port	1
2	136-MCV200	2" Poly Flanged Check Valve	1
3	105-FC200	2" Manifold Clamp	4
4	105-200150BRB	2" Manifold X 1-1/2" Barb	1
5	105-150G	1 1/2" EPDM Gasket	4
6	105-200MPT	2" Manifold x 2" MPT	1
7	100-075PLUG	3/4" Pipe Plug	1
8	716-01-100150	Poly 2" Mixing Chamber	1
9	101-200150	2" MPT x 1-1/2" HB	1
10	105-200PLG050	2" Manifold Plug x 1/2" FPT	1
11	716-333-0011-102	1/2" SS Check Valve—12PSI	1
12	113-06-038050	QC to MPT - 3/8" QC x 1/2" MPT	1



General Instructions:

- 1. Assemble Mixing Chamber fittings as shown.
- 2. Connect hose coming from each pump (after the flowmeter) to inlet hose barbs or quick connect fitting.
- 3. Connect hose from system (Section Valves, LiquiShift®, Flow Indicators, etc.) to outlet hose barb.