

396-6901Y1 Row Control Master Valve Installation Guide & Parts Breakdown

Sentinel Software 1.5.3 Required

For existing systems-

Step 1: Remove the 207-3462Y1 or Y2 harness and replace with the 207-3464Y1 that has the master valve connection that will then connect to the 2" master valve that is in these kits.


Step 2: Remove inlet plumbing fittings and add valve according to the pictures for your pump model.

Note: We recommended installing according to these pictures. If this isn't possible with existing pump mounting, it is recommended to install the valve on the inlet side of the pump.

For new systems-

Step 1: Install the 207-3464Y1 harness to the proper connection points. Step 2: Install the valve according to the images below for your pump model.

Row Control 2" Master Valve Kit PR 17/PR 30 Pumps Kit #-522-04-100101




	ltem #	Part #	Description	Qty
]	1		2" - 3 Wire - WP Connector -	
		103-MEVX200A	EVX Style	1
	2	105-FC200	2" Manifold Clamp	2
	3		1-1/2" EPDM Manifold Gasket	
		105-150G-H	for 200 Series Manifold fittings	2
	4	105-200CPG	2" Manifold Coupling	1
	5	353-30WL	Size 30 Wraplock Band	2
			Final Cable for SurePoint Row	
	6		Control System (pwm, flow,	
		207-3464Y1	pres., pump rpm, master)	1




396-6901Y1 Row Control Master Valve Installation Guide & Parts Breakdown

Row Control 2" Master Valve Kit PR 40/D 250 Pumps Kit #-522-04-100102



ltem #	Part #	Description	Qty
1		2" - 3 Wire - WP Connector - EVX	
L	103-MEVX200A	Style	1
2	105-FC200	2" Manifold Clamp	1
2		1-1/2" EPDM Manifold Gasket for	
3	105-150G-H	200 Series Manifold fittings	1
		Final Cable for SurePoint Row	
4		Control System (pwm, flow, pres.,	
	207-3464Y1	pump rpm, master)	1

Row Control 2" Master Valve Kit PR 80 Pump Kit #-522-04-100103



ltem #	Dort #	Description	Ot v
itein #	Pall#	Description	Qty
1		2" - 3 Wire - WP Connector -	
	103-MEVX200A	EVX Style	1
2			
2	105-FC200	2" Manifold Clamp	2
2		1-1/2" EPDM Manifold Gasket	
3	105-150G-H	for 200 Series Manifold fittings	2
4			
4	105-FC220	2" Full Port Manifold Clamp	1
		(FOR FC220s) 2" EPDM Mani-	
5		fold Gasket for 220 Series	
	105-200G-H	Manifold Fittings	1
~		2" Full Port Manifold x 2" Mani-	
6	105-220200CPG	fold Coupler	2
		Final Cable for SurePoint Row	
7		Control System (pwm, flow,	
	207-3464Y1	pres., pump rpm, master)	1