


Installing Arag 3" E-Mag Meter In QuickDraw Gen2

July 2020

NOTE: When upgrading to Arag meter, the calibration constant (pulses/gallon carrier flow) on the settings page, must be change to 91. Fine tuning of calibration constant my be necessary to increase accuracy.



Grind/remove mounting legs from 3" TEE in top of QD. (Not visible in this picture.)

Loosen clamp and rotate to extend 3" wire braid hose gaining approx. 1.5-2" in vertical height.

Install new 3" E-Mag Meter. Use adapter cable (201-17842) to connect to harness.